



Technical Information

Products: bizhub C208 C258 C368 227 287 367

Subject

Enabling the Web Browser

Background

The web browser is now standard with these models of MFP however this will need enabling before it can be used. And will require a License which is FOC. Enabling the web browser restricts some functions, see the second page for further details. Installing the optional 2GB memory (UK-211) restores these functions.

Enabling the Web Browser

When connected to the internet

- To enable the Web browser function, this machine is automatically connected to the License Management Server (LMS) on the Internet in order to register the license. Check that this machine can be connected to the Internet before beginning this procedure.
- 1. Tap [Utility] - [Administrator Settings] - [Network Settings] - [Web Browser Setting] - [Web Browser Usage Settings].
- 2. Select [ON], then tap [OK].

This machine restarts automatically, and the Web browser becomes available.

Note : This also fails if connected to the internet via a PROXY server.

When not connected to the internet

If this machine cannot be connected to the License Management Server (LMS), you need to manually register the license. Before enabling the Web browser function, access the Web site of the License Management Server through the computer, then obtain license information required to enable the Web browser function.

Select [Utility] - [Device Information] to display the serial number of this machine, then write down it.

Open the Web browser through a computer connected to the Internet, and connect this machine to the Web site of the License Management Server (LMS).



<https://lms.konicaminolta.com/activate>

Enter the serial number of this machine on the Web site of the License Management Server (LMS).

A license code is issued.

3. Register license information on this machine

- If the file required to enable the license is stored on the USB memory, insert the USB memory device into this machine, and then select [Install License from Ext. Memory]. Select [Yes] and tap [OK] to start processing to enable the Web browser function.
- To manually enter the license code, select [Function/License Code], enter the license code, and then tap [Install]. Select [Yes] and tap [OK] to start processing to enable the Web browser function.

This machine restarts automatically, and the Web browser becomes available.

	Standard setting (web browser OFF)	Standard setting (web browser ON)	Optional 2 GB memory installed
Web browser	No	Yes	Yes
IWS	No	Yes	Yes
Google Cloud Print	No	Yes	Yes
Open API	Yes	Yes	Yes
bizhub Remote Access	Yes	Yes	Yes
Banner printing	Yes	Yes	Yes
Addition of image when copying ^{*1}	Yes (Registered overlay is not supported)	No	Yes
Addition of image when printing ^{*2}	Yes (Registered overlay is not supported)	No	Yes
Copy protect ^{*3}	Yes	No	Yes
Copy protection utility	Yes	No	Yes
Insert image at the back when copying	No	Yes	Yes
Long original	Yes	No	Yes

^{*1} Stamp print, watermark, date/time print, page print, header/footer, image overlay, registration overlay, filling number

^{*2} Management number, stamp print, main body of watermark, date/time print, page print, image overlay, registration overlay, filling number

^{*3} Copy protect, copy guard, password copy